

SYNTHIAM

EZ-B Protocol Specification

Last updated: 11/18/2019



Intellectual Property Rights Notice for Specifications Documentation	4
Connection	5
Protocol Commands.....	5
Overview	5
Release All Servos.....	5
Get Unique ID.....	5
Set Battery Monitor Protection State	5
Set Battery Monitor Low Voltage Threshold.....	6
Get Battery Voltage.....	6
Get CPU Temperature	6
UART #0 Init.....	6
UART #1 Init.....	6
UART #2 Init.....	6
UART #0 Write.....	7
UART #1 Write.....	7
UART #2 Write.....	7
UART #0 Get Available Bytes.....	7
UART #1 Get Available Bytes.....	7
UART #2 Get Available Bytes.....	7
UART #0 Get Data from Input Buffer	7
UART #1 Get Data from Input Buffer	8
UART #2 Get Data from Input Buffer	8
I2C Set Clock Speed	8
Restore to Defaults.....	8
I2C Write.....	8
I2C Read.....	8
Set PWM Duty Cycle.....	9
Set Servo Speed.....	9
Set Servo Position.....	9
Set Digital Port ON	9
Set Digital Port OFF	10
Get Digital Port State.....	10
Get ADC Value	10
Send UART on any Digital Port	11
Streaming Audio.....	11
Commands	11

Sync Example Code	12
EZBv4Sound Example Code.....	12
Camera	23
Received Packet	23
Sample Code.....	23
To-Do.....	26

Intellectual Property Rights Notice for Specifications Documentation

- **Technical Documentation.** Synthiam Inc. published this specifications document for EZ-B protocols communication and standards support. Additionally, example source-code documents additional inter-protocol relationships and interactions.
- **Copyrights.** This documentation is covered by Synthiam Inc. copyrights. Regardless of any other terms that are contained in the terms of use for the Synthiam Inc. website that hosts this documentation, you can make copies of it in order to develop implementations of the technologies that are described in this documentation and can distribute portions of it in your implementations that use Synthiam Inc. technologies or in your documentation as necessary to properly document the implementation. You can also distribute in your implementation, with or without modification, any schemas, IDLs, or code samples that are included in the documentation.
- **Trade Secrets.** The communication protocol published in this document is exclusive to the EZ-B family robot controllers and may not be implemented on third party products without written consent from Synthiam Inc.
- **Patents.** Synthiam Inc. may have patents that might cover your implementations of the technologies described in this documentation. Neither this notice nor Synthiam Inc.'s delivery of this documentation grants any licenses under those patents or any other Synthiam Inc. patents. If you would prefer a written license, licenses are available by contacting partners@synthiam.com.
- **Trademarks.** The names of companies and products contained in this documentation might be covered by trademarks or similar intellectual property rights. This notice does not grant any licenses under those rights.
- **Fictitious Names.** The example companies, organizations, products, domain names, email addresses, logos, people, places, and events that are depicted in this documentation may be fictitious. No association with any real company, organization, product, domain name, email address, logo, person, place, or event is intended or should be inferred.
- **Reservation of Rights.** All other rights are reserved, and this notice does not grant any rights other than as specifically described above, whether by implication, estoppel, or otherwise.

Connection

How to connect to EZ-B. Once the TCP connection has been established, the following character (0x55) must be transmitted immediately. One byte will be returned which contains the hardware revision of the EZ-B.

		Notes
Internet Protocol:	TCP	
Default Wi-Fi Mode:	AP Mode (access point)	
Default IP Address:	192.168.1.1	Configurable on EZ-B v4.1/2 and IoTiny
Default Port:	23	Configurable on EZ-B v4.1/2 and IoTiny

Transmit	Receive	Notes
0x55	EZ-B Hardware Revision (1 byte)	EZB_v4_OS_With_Comm_1 = 4, EZB_v4_OS_With_Comm_2 = 42, EZB_v4_OS_IoTiny = 100, Client_Already_Connected = 78, EZB_v3_OS = 166, EZB_v3_BootLoader = 2

Protocol Commands

Overview

- All transmit/receive data commands are 8 bit (1 Byte) unless otherwise specified.
- For additional information regarding supported EZ-B controllers (Arduino, Raspberry Pi, etc) and their firmware, visit <https://synthiam.com/GettingStarted/Build-Robots>

Release All Servos

Stops PWM and Servo PWM on all digital ports.

Transmit	Receive	Notes
0x01	n/a	

Get Unique ID

Every EZ-B has a unique 12 byte ID that can be queried.

Transmit	Receive	Notes
0x02	12 Bytes	

Set Battery Monitor Protection State

Enable or disable the internal EZ-B battery monitor.

Transmit	Receive	Notes
0x04, 0x00, [0x00 / 0x01]	n/a	

Set Battery Monitor Low Voltage Threshold

Specify the low voltage threshold for the battery monitor. The value to be specified is a **little endian 16 bit unsigned INT**, which is the **VOLTAGE / 0.003862434**.

Transmit	Receive	Notes
0x04, 0x01, <unsigned 16 bit value>	n/a	16 bit value is little endian.

Get Battery Voltage

Returns the battery voltage of the EZ-B. The returned value is a **little endian unsigned 16 bit INT**. To get voltage, multiple the value by 0.003862434m. This means the **voltage = RETURN VALUE * 0.003862434**.

Transmit	Receive	Notes
0x04, 0x02	<unsigned 16 bit value>	16 bit value is little endian.

Get CPU Temperature

Returns the temperature of the EZ-B CPU. The returned value is a **little endian unsigned 16 bit INT**. To get temperature in Celsius, multiple the value by 0.026341480261472. This means the **temperature = RETURN VALUE * 0.026341480261472**.

Transmit	Receive	Notes
0x04, 0x03	<unsigned 16 bit value>	16 bit value is little endian.

UART #0 Init

Initialize the UART #0 port on the EZ-B with the **specified baud rate** as a **little endian unsigned 32 bit INT**. This also clears the UART input buffer on the EZ-B.

Transmit	Receive	Notes
0x04, 0x05, <unsigned 32 bit value>	n/a	32 bit baud rate value is little endian.

UART #1 Init

Initialize the UART #1 port on the EZ-B with the **specified baud rate** as a **little endian unsigned 32 bit INT**. This also clears the UART input buffer on the EZ-B.

Transmit	Receive	Notes
0x04, 0x09, <unsigned 32 bit value>	n/a	32 bit baud rate value is little endian.

UART #2 Init

Initialize the UART #2 port on the EZ-B with the **specified baud rate** as a **little endian unsigned 32 bit INT**. This also clears the UART input buffer on the EZ-B.

Transmit	Receive	Notes
0x04, 0x0D, <unsigned 32 bit value>	n/a	32 bit baud rate value is little endian.

UART #0 Write

Write data out of the UART #0 port on the EZ-B. The length of the data is specified as a ***little endian unsigned 16 bit INT***.

Transmit	Receive	Notes
0x04, 0x06, <unsigned 16 bit value data length>, DATA BYTES...	n/a	16 bit value is little endian.

UART #1 Write

Write data out of the UART #1 port on the EZ-B. The length of the data is specified as a ***little endian unsigned 16 bit INT***.

Transmit	Receive	Notes
0x04, 0x0A, <unsigned 16 bit value data length>, DATA BYTES...	n/a	16 bit value is little endian.

UART #2 Write

Write data out of the UART #2 port on the EZ-B. The length of the data is specified as a ***little endian unsigned 16 bit INT***.

Transmit	Receive	Notes
0x04, 0x0E, <unsigned 16 bit value data length>, DATA BYTES...	n/a	16 bit value is little endian.

UART #0 Get Available Bytes

Get the available number of bytes in the UART #0 input buffer. The returned length is a ***little endian unsigned 16 bit INT***.

Transmit	Receive	Notes
0x04, 0x07	<unsigned 16 bit>	16 bit returned value is little endian.

UART #1 Get Available Bytes

Get the available number of bytes in the UART #1 input buffer. The returned length is a ***little endian unsigned 16 bit INT***.

Transmit	Receive	Notes
0x04, 0x0B	<unsigned 16 bit>	16 bit returned value is little endian.

UART #2 Get Available Bytes

Get the available number of bytes in the UART #2 input buffer. The returned length is a ***little endian unsigned 16 bit INT***.

Transmit	Receive	Notes
0x04, 0x0F	<unsigned 16 bit>	16 bit returned value is little endian.

UART #0 Get Data from Input Buffer

Get the specified number of bytes from the UART #0 input buffer. The specified length is a ***little endian unsigned 16 bit INT***.

Transmit	Receive	Notes
0x04, 0x08, <unsigned 16 bit length>	<Multiple bytes as specified>	16 bit value is little endian.

UART #1 Get Data from Input Buffer

Get the specified number of bytes from the UART #1 input buffer. The specified length is a **little endian unsigned 16 bit INT**.

Transmit	Receive	Notes
0x04, 0x0C, <unsigned 16 bit length>	<Multiple bytes as specified>	16 bit value is little endian.

UART #2 Get Data from Input Buffer

Get the specified number of bytes from the UART #2 input buffer. The specified length is a **little endian unsigned 16 bit INT**.

Transmit	Receive	Notes
0x04, 0x10, <unsigned 16 bit length>	<Multiple bytes as specified>	16 bit value is little endian.

I2C Set Clock Speed

Specify the clock speed of the i2c interface. The specified length is a **little endian unsigned 32 bit INT**.

Transmit	Receive	Notes
0x04, 0x11, <unsigned 32 bit speed>	n/a	32 bit value is little endian.

Restore to Defaults

Restore the EZ-B to default factory settings.

Transmit	Receive	Notes
0x04, 0x13	n/a	32 bit value is little endian.

I2C Write

Write data out of the I2C port on the EZ-B. The length of the data is specified as an **unsigned 8 bit INT**.

Transmit	Receive	Notes
0x0A, <unsigned 8 bit byte i2c address>, <unsigned 8 bit bytes to send>, DATA BYTES...	n/a	

I2C Read

Get the specified number of bytes from the I2C input buffer. The specified length is an **unsigned 8 bit INT**.

Transmit	Receive	Notes
0x0B, <unsigned 8 bit byte i2c Address>, <unsigned 8 bit bytes to read>	<Multiple bytes as specified by request>	

Set PWM Duty Cycle

Specify the PWM Duty Value to be outputted on the specified digital port. The *Port Index* is the digital port to be outputted starting with D0. The PWM value is between 0 and 100.

Example of 0% duty on D3: *0x12, 0x00*

Example of 75% duty on D8: *0x17, 0x4B*

Transmit	Receive	Notes
<i>0x0F + <Port Index>, <unsigned 8 bit duty></i>	<i>n/a</i>	

Set Servo Speed

Specify the Servo Speed for the specified digital port. The *Port Index* is the digital port to be outputted starting with D0.

*Note: A servo position must be specified before the servo speed can be set.

Example of setting servo speed to 3 on D3: *0x2A, 0x03*

Transmit	Receive	Notes
<i>0x27 + <Port Index>, <unsigned 8 bit speed></i>	<i>n/a</i>	

Set Servo Position

Specify the Servo Position for the specified digital port. The *Port Index* is the digital port to be outputted starting with D0. The position is in degrees between 1 and 180 (specify 0 to release the servo PWM).

Example of setting servo on Port D3 to position 90: *0xAF, 0x5A*

Example of setting servo on Port D18 to position 145: *0xBE, 0x91*

Transmit	Receive	Notes
<i>0xAC + <Port Index>, <unsigned 8 bit position></i>	<i>n/a</i>	

Set Digital Port ON

Specify the Digital Port to be in the ON (true) state on the specified digital port. The *Port Index* is the digital port to be outputted starting with D0.

Example of TRUE on D3: *0x67*

Example of TRUE on D8: *0x6C*

Transmit	Receive	Notes
<i>0x64 + <Port Index></i>	<i>n/a</i>	

Set Digital Port OFF

Specify the Digital Port to be in the OFF (false) state on the specified digital port. The *Port Index* is the digital port to be outputted starting with D0.

Example of TRUE on D3: 0x7F

Example of TRUE on D8: 0x84

Transmit	Receive	Notes
0x7C + <Port Index>	n/a	

Get Digital Port State

Get the state of the specified digital port. The *Port Index* is the digital port to starting with D0. Once the port is read, this puts the port into INPUT mode.

Example of getting value of port D3: 0x97

Example of TRUE on D8: 0x9C

Transmit	Receive	Notes
0x94 + <Port Index>	[0x00 0x01]	Returns a 0 (false) or 1 (true) of the state of the digital port.

Get ADC Value

Get the ADC Value of the specified analog port. The *Port Index* is the ADC (analog) port to be read starting with ADC0.

Example of reading ADC value on port ADC3: 0xC7

Transmit	Receive	Notes
0xC4 + <Port Index>	<unsigned 16 bit INT>	

Send UART on any Digital Port

Send the specified data to any digital port at one of the supported baud rates.

Baud_4800 = 0,

Baud_9600 = 1,

Baud_19200 = 2,

Baud_38400 = 3,

Baud_57600 = 4,

Baud_115200 = 5

Example of writing 'HELLO' to port D3 at 9600: 0xCF, 0x01, 0x05, 0x48, 0x45, 0x4C, 0x4C, 0x4F

Transmit	Receive
0xCC + <Port Index>, <unsigned 8 bit value baud rate>, <unsigned 8 bit value data size>, DATA...	n/a

Streaming Audio

The EZ-B uses a raw 8 bit mono PCM stream at 14.7kHz (14,700hz) for the DAC to play audio. The EZ-B has an internal 50k buffer for audio. The audio data is sent to the EZ-B and the DAC can be enabled to begin playing the data within the buffer. Once the DAC is enabled, you must continue streaming data at the EZ-B at the rate of 14.7kHz. This can be done using a calculation to determine how long to pause for.

Commands

Load data into the EZ-B buffer

```
// build the packet including the LOAD command (0x01) and audio data bytes
List<byte> dataTmp = new List<byte>();
dataTmp.Add(0x01);
dataTmp.AddRange(BitConverter.GetBytes((UInt16)audioData));
dataTmp.AddRange(bTmp.Take(audioData));

// send the constructed packet to the ez-b
ezb.sendCommand(0xfe, dataTmp.ToArray());
```

Begin playing the EZ-B's audio buffer

```
// instruct the ezb to begin playing the DAC audio buffer
ezb.sendCommand(0xfe, 0x02);
```

Stop the EZ-B's DAC audio play

```
ezb.sendCommand(0xfe, 0x00);
```

Sync Example Code

To sync your client with the playback frequency of the EZ-B (14.7khz), this is an example code.

```
// Use the stop watch to determine how long we have been playing for
// the stop watch begins at the start of the playback (after initial load of data)
float runtime = (float)sw.ElapsedMilliseconds;

// convert milliseconds to seconds. Multiple the seconds by the audio bit rate.
// this gets us where we should be in the stream.
// We add the prebuffer length because we don't actually wait and play during the prebuffer, as the pre
// buffer is transmitted in one chunk with no delays.
// Also, the stop watch doesn't start until the audio begins to play after prebuffer.
float shouldBeAtSamplePosition = ((runtime / 1000f) * (float)AUDIO_SAMPLE_BITRATE) +
(float)_afterBuffer.Length;

// check to see if we are behind on the stream based on how long the audio has been playing in samples.
float difference = _position - shouldBeAtSamplePosition;

// if there is a difference, wait some time and let the ez-b buffer play and catch up
if (difference > 0) {

    // convert the sample difference to a millisecond time so we know how long to sleep and let the ez-b
    catch up
    float delay = (difference / AUDIO_SAMPLE_BITRATE) * 1000;

    Thread.Sleep((int)delay);
}
```

EZBv4Sound Example Code

This is a C# example of how to play back an audio stream to the EZ-B for your reference

```
using System;
using System.Collections.Generic;
using System.Diagnostics;
using System.IO;
using System.Linq;
using System.Threading;

namespace EZ_B {

    public class EZBv4Sound : DisposableBase {

        class ThreadStartParams {

            public int CNT;
            public MemoryStream AudioStream;

            public ThreadStartParams(int cnt, MemoryStream audioStream) {

                CNT = cnt;
                AudioStream = audioStream;
            }
        }
    }
}
```

```

EZB      _ezb;
EZTaskScheduler _tsSound    = null;
int      _playFromSample = 0;
volatile int _cnt          = 0;
int      _position        = 0;
bool     _isPlaying       = false;

byte [] _rampUp = new byte[256];
byte [] _rampDown = new byte[256];

// Appended to end of all audio streams to compensate for the time it takes to pre-buffer
byte [] _afterBuffer;

/// <summary>
/// The recommended size of the the audio packets
/// </summary>
public static readonly int RECOMMENDED_PACKET_SIZE = 256;

/// <summary>
/// The recommended size of the prebuffer before playing the audio
/// </summary>
public static readonly int RECOMMENDED_PREBUFFER_SIZE = 20000;

/// <summary>
/// The sample rate at which the data is played back on the EZ-B
/// </summary>
public static readonly int AUDIO_SAMPLE_BITRATE = 14700;

/// <summary>
/// The size of each packet which is transmitted over the wire to the EZ-B.
/// </summary>
public int PACKET_SIZE = RECOMMENDED_PACKET_SIZE;

/// <summary>
/// The ammount of data to prebuffer to the EZ-B before playing the audio. The EZ-B has a 50k buffer, so this value
cannot be any higher than that.
/// </summary>
public int PREBUFFER_SIZE = RECOMMENDED_PREBUFFER_SIZE;

/// <summary>
/// Event execeuted when new data is being sent to the EZ-B
/// </summary>
public delegate void OnAudioDataHandler(int minVal, int maxVal, int avgVal);

/// <summary>
/// Event executed when the volume value has changed
/// </summary>
public delegate void OnVolumeChangedHandler(decimal volume);

/// <summary>
/// Event executed when the audio has stopped playing

```

```

/// </summary>
public delegate void OnStopPlayingHandler();

/// <summary>
/// Event executed when the audio has begun playing
/// </summary>
public delegate void OnStartPlayingHandler();

/// <summary>
/// Event executed when the audio level is clipping. This means the volume value is amplifying the audio past the limits
/// </summary>
public delegate void OnClippingStatusHandler(bool isClipping);

public event OnAudioDataHandler OnAudioDataChanged;
public event OnVolumeChangedHandler OnVolumeChanged;
public event OnStopPlayingHandler OnStopPlaying;
public event OnStartPlayingHandler OnStartPlaying;
public event OnClippingStatusHandler OnClippingStatus;

private decimal _volume = 100;

/// <summary>
/// Returns status if music is playing
/// </summary>
public bool IsPlaying {
    get {
        return _isPlaying;
    }
}

/// <summary>
/// Get or Set the volume
/// </summary>
public decimal Volume {
    get {
        return _volume;
    }
    set {
        if (_volume != value && OnVolumeChanged != null)
            OnVolumeChanged(value);

        _volume = value;
    }
}

protected internal EZBv4Sound(EZB ezb) {

    _ezb = ezb;

    for (int x = 0; x < _rampUp.Length; x++)

```

```

    _rampUp[x] = (byte)(x / 2);

    for (int x = 0; x < 64; x++)
        _rampDown[x] = (byte)(128 - (x * 2));

    initAfterBufferArrays();

    _tsSound = new EZTaskScheduler("v4 Sound");
    _tsSound.OnEventToRun += threadStreamAudio;
    _tsSound.OnEventStart += _tsSound_OnEventStart;
    _tsSound.OnEventCompleted += _tsSound_OnEventCompleted;
}

private void _tsSound_OnEventStart(int taskId, object o) {

    _isPlaying = true;
}

private void _tsSound_OnEventCompleted(int taskId, object o) {

    _isPlaying = false;
}

void initAfterBufferArrays() {

    if (_afterBuffer == null || _afterBuffer.Length != PREBUFFER_SIZE) {

        _afterBuffer = new byte[PREBUFFER_SIZE];

        for (int x = 0; x < _afterBuffer.Length; x++)
            _afterBuffer[x] = 0;
    }
}

/// <summary>
/// Play the Audio Data out of the EZ-B.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// </summary>
public void PlayDataWait(byte[] data) {

    PlayDataWait(null, data, _volume, new int[] { }, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// </summary>
public void PlayData(byte[] data) {

    PlayData(null, data, _volume, new int[] { }, 0);
}

```

```

}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// </summary>
public void PlayData(byte[] data, decimal volume) {

    PlayData(null, data, volume, new int[] { }, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// </summary>
public void PlayData(byte[] data, decimal volume) {

    PlayData(null, data, volume, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// </summary>
public void PlayDataWait(byte[] data, decimal volume) {

    PlayDataWait(null, data, volume, new int[] { }, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// *Note: You must dispose of the memory stream yourself after calling this
/// </summary>
public void PlayData(Stream ms) {

    PlayData(ms, null, _volume, new int[] { }, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// *Note: You must dispose of the memory stream yourself after calling this
/// </summary>
public void PlayData(Stream ms) {

```



```

    PlayData(ms, null, _volume, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// *Note: You must dispose of the memory stream yourself after calling this
/// </summary>
public void PlayData(Stream ms, int playFromSample) {

    PlayData(ms, null, _volume, playFromSample);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// *Note: You must dispose of the memory stream yourself after calling this
/// </summary>
public void PlayDataWait(Stream ms) {

    PlayDataWait(ms, null, _volume, new int[] { }, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// *Note: You must dispose of the memory stream yourself after calling this
/// </summary>
public void PlayData(Stream ms, decimal volume) {

    PlayData(ms, null, volume, new int[] { }, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// *Note: You must dispose of the memory stream yourself after calling this
/// </summary>
public void PlayData(Stream ms, decimal volume) {

    PlayData(ms, null, volume, 0);
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.
/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate

```

```

/// *Note: You must dispose of the memory stream yourself after calling this
/// </summary>
public void PlayData(Stream ms, byte[] bytes, decimal volume, int playFromSample) {

    Stop();

    if (!_ezb.IsConnected)
        return;

    if (_ezb.EZBType != EZB.EZ_B_Type_Enum.ezb4) {

        _ezb.Log(false, "This feature is only available for EZ-B v4");

        return;
    }

    initAfterBufferArrays();

    MemoryStream tmpMs = new MemoryStream();

    if (_ezb.GetFirmwareVersionEnum() == EZB.FirmwareVersionEnum.EZB_v4_OS_1oTiny)
        tmpMs.Write(_rampUp, 0, _rampUp.Length);

    if (ms != null)
        ms.CopyTo(tmpMs);
    else if (bytes != null)
        tmpMs.Write(bytes, 0, bytes.Length);
    else
        throw new Exception("Expecting either a memorystream or byte array of audio");

    if (_ezb.GetFirmwareVersionEnum() == EZB.FirmwareVersionEnum.EZB_v4_OS_1oTiny)
        tmpMs.Write(_rampDown, 0, _rampDown.Length);

    if (tmpMs.Length == 0)
        return;

    tmpMs.Write(_afterBuffer, 0, _afterBuffer.Length);

    _playFromSample = playFromSample;

    tmpMs.Position = playFromSample;

    Volume = volume;

    _cnt++;

    _tsSound.StartNew(new ThreadStartParams(_cnt, tmpMs));
}

/// <summary>
/// Stream raw audio data to the EZ-B v4's speakers.

```

```

/// 0 is silent, 100 is normal, 200 is 2x gain, 300 is 3x gain, etc.
/// The audio must be RAW 8 Bit at 18 KHZ Sample Rate
/// *Note: You must dispose of the memory stream yourself after calling this
/// </summary>
public void PlayDataWait(Stream ms, byte[] bytes, decimal volume, int playFromSample) {

    Stop();

    if (!_ezb.IsConnected)
        return;

    if (_ezb.EZBType != EZB.EZ_B_Type_Enum.ezb4) {

        _ezb.Log(false, "This feature is only available for EZ-B v4");

        return;
    }

    initAfterBufferArrays();

    MemoryStream tmpMs = new MemoryStream();

    if (_ezb.GetFirmwareVersionEnum() == EZB.FirmwareVersionEnum.EZB_v4_OS_1oTiny)
        tmpMs.Write(_rampUp, 0, _rampUp.Length);

    if (ms != null)
        ms.CopyTo(tmpMs);
    else if (bytes != null)
        tmpMs.Write(bytes, 0, bytes.Length);
    else
        throw new Exception("Expecting either a memorystream or byte array of audio");

    if (_ezb.GetFirmwareVersionEnum() == EZB.FirmwareVersionEnum.EZB_v4_OS_1oTiny)
        tmpMs.Write(_rampDown, 0, _rampDown.Length);

    if (tmpMs.Length == 0)
        return;

    tmpMs.Write(_afterBuffer, 0, _afterBuffer.Length);

    _playFromSample = playFromSample;

    tmpMs.Position = playFromSample;

    Volume = volume;

    _cnt++;

    threadStreamAudio(0, new ThreadStartParams(_cnt, tmpMs));
}

```

```

void threadStreamAudio(int taskId, object o) {

    ThreadStartParams threadStartParams = (ThreadStartParams)o;

    if (_cnt != threadStartParams.CNT || !_ezb.IsConnected)
        return;

    Stopwatch sw = new Stopwatch();

    try {

        if (OnStartPlaying != null)
            OnStartPlaying();

        _ezb.sendCommand(EZB.CommandEnum.CmdSoundStreamCmd, (byte)EZB.CmdSoundv4Enum.CmdSoundInitStop);

        bool playing = false;

        _position = 0;

        byte[] bTmp = new byte[PREBUFFER_SIZE];

        do {

            int bytesRead;

            if (playing)
                bytesRead = threadStartParams.AudioStream.Read(bTmp, 0, PACKET_SIZE);
            else
                bytesRead = threadStartParams.AudioStream.Read(bTmp, 0, PREBUFFER_SIZE);

            _position += bytesRead;

            bool isClipping = false;
            int highest = 0;
            int lowest = 255;
            int average = 0;
            long total = 0;
            decimal volumeMultiplier = _volume / 100m;

            if (_volume != 100 || OnAudioDataChanged != null)
                for (int x = 0; x < bytesRead; x++) {

                    decimal newVal = (decimal)bTmp[x];

                    if (newVal > 128)
                        newVal = Math.Max(128, 128 + ((newVal - 128) * volumeMultiplier));
                    else if (newVal < 128)
                        newVal = Math.Min(128, 128 - ((128 - newVal) * volumeMultiplier));

                    if (newVal > 255) {

```

```

        newVal = 255;

        isClipping = true;
    } else if (newVal < 0) {

        newVal = 0;

        isClipping = true;
    }

    highest = Math.Max(highest, (int)newVal);
    lowest = Math.Min(lowest, (int)newVal);
    total += (int)newVal;

    bTmp[x] = (byte)newVal;
}

average = (int)(total / bytesRead);

List<byte> dataTmp = new List<byte>();
dataTmp.Add((byte)EZB.CmdSoundv4Enum.CmdSoundLoad);
dataTmp.AddRange(BitConverter.GetBytes((UInt16)bytesRead));
dataTmp.AddRange(bTmp.Take(bytesRead));

if (_cnt != threadStartParams.CNT)
    return;

_zeb.sendCommand(EZB.CommandEnum.CmdSoundStreamCmd, dataTmp.ToArray());

if (_cnt != threadStartParams.CNT)
    return;

if (!playing && _position >= PREBUFFER_SIZE) {

    _zeb.sendCommand(EZB.CommandEnum.CmdSoundStreamCmd, (byte)EZB.CmdSoundv4Enum.CmdSoundPlay);

    playing = true;

    sw.Start();
}

if (OnAudioDataChanged != null)
    OnAudioDataChanged(lowest, highest, average);

if (playing) {

    if (OnClippingStatus != null)
        OnClippingStatus(isClipping);

    float runtime = (float)sw.ElapsedMilliseconds;

```

```

    // convert milliseconds to seconds. Multiple the seconds by the audio bit rate.
    // this gets us where we should be in the stream.
    // We add the prebuffer lengthh because we don't actually wait and play during the prebuffer, as the pre buffer is
transmitted in one chunk with no delays.
    // Also, the stop watch doesn't start until the audio begins to play after prebuffer.
    float shouldBeAtSamplePosition = ((runtime / 1000f) * (float)AUDIO_SAMPLE_BITRATE) +
(float)_afterBuffer.Length;

    // check to see if we are behind on the stream based on how long the audio has been playing in samples.
    float difference = _position - shouldBeAtSamplePosition;

    // if there is a difference, wait some time and let the ez-b buffer play and catch up
    if (difference > 0) {

        // convert the sample difference to a millisecond time so we know how long to sleep and let the ez-b catch up
        float delay = (difference / AUDIO_SAMPLE_BITRATE) * 1000;

        Thread.Sleep((int)delay);
    }
}
} while (_position < threadStartParams.AudioStream.Length && _ezb.IsConnected && _cnt ==
threadStartParams.CNT);

} catch (Exception ex) {

    _ezb.Log(false, "Error Streaming Audio: {0}", ex);
} finally {

    sw.Stop();

    threadStartParams.AudioStream.Dispose();

    if (_ezb.IsConnected)
        _ezb.sendCommand(EZB.CommandEnum.CmdSoundStreamCmd,
(byte)EZB.CmdSoundv4Enum.CmdSoundInitStop);

    if (OnClippingStatus != null)
        OnClippingStatus(false);

    if (OnStopPlaying != null)
        OnStopPlaying();
}
}

/// <summary>
/// Stop the audio which is being played
/// </summary>
public void Stop() {

    _cnt++;

```

```

// a slight amount of time to ensure the audio has stopped before attempting to play new audio
System.Threading.Thread.Sleep(250);
}

/// <summary>
/// Dispose of the AutoPositioner
/// </summary>
protected override void DisposeOverride() {

    OnStartPlaying = null;
    OnStopPlaying = null;

    _tsSound.Dispose();
    _tsSound = null;

    _cnt++;
}
}
}

```

Camera

The camera protocol is a stream of JPG images, each with a header.

Received Packet

Visible image (regular camera): EZIMG<unsigned 16bit int length><jpg data>

Infrared image (IPS camera): EZIRC<unsigned 16bit int length><jpg data>

Sample Code

This is example code from the EZ-B SDK that loops for ever collecting video data, unless there is a disconnect or timeout. In your program, you will want to handle connect and disconnects gracefully. This code is presented as an example only.

```

public class EZBv4VideoSample {

    /// <summary>
    /// Event raised when an infrared image is ready. This image must be disposed after use.
    /// </summary>
    public event OnImageIRReadyHandler OnImageIRReady;
    public delegate void OnImageIRReadyHandler(Bitmap BM);

    /// <summary>
    /// Event raised when the image is ready. This image must be disposed after use.
    /// </summary>
    public event OnImageReadyHandler OnImageReady;
    public delegate void OnImageReadyHandler(Bitmap BM);

    /// <summary>
    /// Event raised when an infrared image is ready.
    /// </summary>
    public event OnImageIRDataReadyHandler OnImageIRDataReady;
    public delegate void OnImageIRDataReadyHandler(byte[] imageData);

    /// <summary>

```

```

/// Event raised when the image is ready.
/// </summary>
public event OnImageDataReadyHandler OnImageDataReady;
public delegate void OnImageDataReadyHandler(byte[] imageData);

readonly byte [] TAG_EZIMAGE = new byte[] { (byte)'E', (byte)'Z', (byte)'I', (byte)'M', (byte)'G'
};
readonly byte [] TAG_EZIRC = new byte[] { (byte)'E', (byte)'Z', (byte)'I', (byte)'R', (byte)'C'
};

readonly int BUFFER_SIZE = 128000;

void imageThreadWorker() {

    List<byte> bufferImage = new List<byte>();
    byte[] bufferTmp = new byte[BUFFER_SIZE];

    try {

        using (var tcpClient = new TcpClient()) {

            IAsyncResult ar = tcpClient.BeginConnect(threadStartParams.IPAddress,
threadStartParams.Port, null, null);

            if (!ar.AsyncWaitHandle.WaitOne(TimeSpan.FromSeconds(3), false))
                throw new TimeoutException();

            tcpClient.EndConnect(ar);

            tcpClient.ReceiveBufferSize = BUFFER_SIZE;
            tcpClient.NoDelay = true;
            tcpClient.ReceiveTimeout = 5000;
            tcpClient.SendTimeout = 3000;

            using (NetworkStream ns = tcpClient.GetStream())
                while (tcpClient.Connected) {

                    int read = ns.Read(bufferTmp, 0, BUFFER_SIZE);

                    if (read == 0)
                        throw new Exception("Client disconnected");

                    bufferImage.AddRange(bufferTmp.Take(read));

                    if (bufferImage.Count > 512000)
                        throw new Exception(string.Format("Image data is piling up and not being processed.
We stopped the collection at {0:###,###} Bytes. Post on the forum so we can better understand what is
happening and fix it.", bufferImage.Count));

                    LOOP_AGAIN:
                    ImageTypeEnum imageType = ImageTypeEnum.NA;
                    int foundStart = -1;

                    if (bufferImage.Count < TAG_EZIMAGE.Length)
                        continue;

                    for (int p = 0; p < bufferImage.Count - TAG_EZIMAGE.Length; p++)
                        if (bufferImage[p] == TAG_EZIMAGE[0] &&
                            bufferImage[p + 1] == TAG_EZIMAGE[1] &&
                            bufferImage[p + 2] == TAG_EZIMAGE[2] &&
                            bufferImage[p + 3] == TAG_EZIMAGE[3] &&
                            bufferImage[p + 4] == TAG_EZIMAGE[4]) {

```



```

        imageType = ImageTypeEnum.Camera;

        foundStart = p;

        break;
    } else if (bufferImage[p] == TAG_EZIRC[0] &&
        bufferImage[p + 1] == TAG_EZIRC[1] &&
        bufferImage[p + 2] == TAG_EZIRC[2] &&
        bufferImage[p + 3] == TAG_EZIRC[3] &&
        bufferImage[p + 4] == TAG_EZIRC[4]) {

        imageType = ImageTypeEnum.Infrared;

        foundStart = p;

        break;
    }

    if (foundStart == -1)
        continue;

    if (foundStart > 0)
        bufferImage.RemoveRange(0, foundStart);

    if (bufferImage.Count < TAG_EZIMAGE.Length + sizeof(UInt32))
        continue;

    int imageSize = (int)BitConverter.ToUInt32(bufferImage.GetRange(TAG_EZIMAGE.Length,
sizeof(UInt32)).ToArray(), 0);

    if (bufferImage.Count <= imageSize + TAG_EZIMAGE.Length + sizeof(UInt32))
        continue;

    bufferImage.RemoveRange(0, TAG_EZIMAGE.Length + sizeof(UInt32));

    _imageSize = imageSize;

    try {

        if (imageType == ImageTypeEnum.Camera) {

            if (OnImageReady != null)
                OnImageReady(new Bitmap(new MemoryStream(bufferImage.GetRange(0,
imageSize).ToArray())));

            if (OnImageDataReady != null)
                OnImageDataReady(bufferImage.GetRange(0, imageSize).ToArray());
        } else if (imageType == ImageTypeEnum.Infrared) {

            if (OnImageIRReady != null)
                OnImageIRReady(new Bitmap(new MemoryStream(bufferImage.GetRange(0,
imageSize).ToArray())));

            if (OnImageIRDataReady != null)
                OnImageIRDataReady(bufferImage.GetRange(0, imageSize).ToArray());
        }
    } catch (Exception ex) {

        _ezb.Log(false, "ezbv4 camera image render error: {0}", ex);
    }
}

```

```
        bufferImage.RemoveRange(0, imageSize);

        // If there's at least 5kb of data in the buffer, loop again and see if there's another
image in the buffer
        // Without doing this, there's a chance the buffer will fill with future images and
we'll never catch up because image data is only processed when an image is available
        if (bufferImage.Count > 5000)
            goto LOOP_AGAIN;
    }
} catch (Exception ex) {
    _ezb.Log(false, "EZ-B v4 Camera Error: {0}", ex);
}
}
```

To-Do

EZ-B protocol commands not yet specified in this document include...

- Ultrasonic Distance Sensor
- Built-in Audio Samples